

Unpacking Guide



Make sure box in right orientation



Remove foam cover



Remove all the auxiliary content and foam before moving the laser cutter unit (recommended)

LCD Monitor Box

Cutting material

Power Cable

Ducting Adaptor


Wheels

CraftLaser Unit

Handle

Handle





LCD Monitor:

- The Red receptacle is the power input,
- The Yellow receptacle for the video input from the RCA cable
- The White receptable is not used (audio in)

SD Cards:

- The Green labelled SD card is loaded with Electronic manual and test cut files